

HOST OVERVIEW

Mechanical Coverage by Tint.

A plain-English guide for Turo hosts – what's covered, what's not, and what to do when something breaks.

KEY DETAILS

WAITING PERIOD

30 days & 1,000 mi

Both must be met before mechanical coverage begins – whichever comes last.

DEDUCTIBLE

\$100 · \$250 · \$500

Three flexible options, selected at sign-up.

COVERAGE AREA

USA only

Not available in California, Massachusetts, or Florida.

VEHICLE ELIGIBILITY

Year 2014+ · <150k mi

Model year 2014 or newer with under 150,000 miles at sign-up. Listed on Turo, non-exotic.

INCLUDED ON EVERY PLAN

1,000+ parts

Covered across engine, drivetrain, electrical, and more.

\$125 roadside

Towing, jump-start, flat tire, lockout, and fuel delivery – per occurrence.

\$100 / day

Trip interruption: up to 3 days of lodging + meals, when 150+ mi from home.

\$30 / day

Rental reimbursement: up to 5 days during any authorized repair lasting 4+ hours.

GOOD TO KNOW

Keep maintenance records

Follow the manufacturer-recommended service schedule to keep your coverage valid.

30-day free cancellation

Cancel within 30 days and get a full refund – as long as no claims have been filed.

Transfer for \$50

Selling the car? Coverage transfers to the new owner for a one-time \$50 fee.

218
COMPONENTS

Turn the page for the full coverage chart →

Every part, across all three plans – side-by-side.

DETAILED COVERAGE CHART · PART 1 OF 2

Every covered component, at a glance.

218 components across 14 vehicle systems.

✓ covered — not covered

BRAKES	PWR	ENH	PRM
ABS system component parts (Hydraulic Control Unit, Electronic Control Processor, Wheel Speed...	—	✓	✓
Backing plates	—	—	✓
Brake lamp switch	—	—	✓
Compensating valve	—	✓	✓
Disc calipers	—	✓	✓
Flexible hydraulic lines and fittings	—	—	✓
Hydro-boost and accumulator	—	✓	✓
Load distribution valves	—	—	✓
Master cylinder	—	✓	✓
Parking brake linkage and cables	—	—	✓
Proportioning valve	—	—	✓
Self-adjusters	—	—	✓
Vacuum assist booster	—	✓	✓
Power Brake Cylinder	—	✓	✓
Wheel cylinders	—	✓	✓
EV/Hybrid Regenerative Braking System	—	—	✓
EV/Hybrid Control Module	—	—	✓

DRIVE AXLE	PWR	ENH	PRM
All internally lubricated parts contained within the Front and/or Rear Drive Axle Housing	—	—	✓
Axle bearings	✓	✓	✓
Axle shafts	✓	✓	✓
Pinion Bearing	✓	✓	✓
Side Carrier Bearing	✓	✓	✓
Ring and Pinion Gears	✓	✓	✓
Carrier Assembly	✓	✓	✓
Thrust Washers	✓	✓	✓
Internal Transaxle Seal	✓	✓	✓
Center support bearing	✓	✓	✓
Constant velocity joints and boots	✓	✓	✓
Dampener	—	—	✓
Drive shafts	—	—	✓
Driveshaft yokes	—	—	✓
Final drive housing when damaged as a result of the failure of a covered internally lubricated part	✓	✓	✓
Flex disk	—	—	✓
Mounts	—	—	✓
Propeller shafts	—	—	✓
Speed pickup sensor	—	—	✓
Universal joints	✓	✓	✓

ELECTRICAL	PWR	ENH	PRM
4WD Encoder	—	✓	✓
Manually Operated Switches	—	✓	✓
Alternator	—	✓	✓
Alternator assembly	—	—	✓
Antenna motor	—	✓	✓
Anti-theft system components	—	—	✓
Auxiliary power outlets	—	—	✓
Clock assembly	—	—	✓
Coolant temperature sensor	—	—	✓
Cooling fan	—	—	✓
Cooling fan motor	—	—	✓
Cooling fan sensor and switch	—	—	✓
Cruise control servo	—	✓	✓
Cruise control vacuum reservoir	—	—	✓
Distributor	—	✓	✓
Electronic timing control sensor	—	—	✓
Factory installed power sunroof motor	—	—	✓
Fuel level sending unit	—	—	✓
Fuel pressure sensor	—	—	✓

ELECTRICAL · CONT.	PWR	ENH	PRM
Fuel tank pressure sensor	—	—	✓
Fuel Injection sensor	—	✓	✓
Fuel Injector	—	✓	✓
GPS navigation components	—	✓	✓
Heated air intake system	—	—	✓
Horn	—	—	✓
Idle air control module	—	—	✓
Infrared System	—	✓	✓
Ignition coil	—	✓	✓
Ignition module	—	✓	✓
Instrument panel gauges	—	✓	✓
Low fuel sensor	—	—	✓
Mirror motors	—	—	✓
Oxygen sensor	—	—	✓
Pick up coil	—	—	✓
Power door lock actuator	—	✓	✓
Power mirror motor	—	✓	✓
Power seat motor	—	✓	✓
Power window motor/regulator	—	✓	✓
Seat heaters	—	—	✓
Speed limiter key/rev limiter	—	—	✓
Starter assembly	—	—	✓
Starter drive	—	—	✓
Starter motor	—	✓	✓
Solenoids	—	—	✓
Rear Window Heating Element	—	✓	✓
Relay	—	—	✓
Throttle sensor	—	—	✓
Vehicle speed sensor	—	—	✓
Voltage rectifier/regulator	—	—	✓
Voltage regulator	—	✓	✓
Wiper motor(s) (front and rear)	—	✓	✓
Wiring harness	—	—	✓

ENGINE	PWR	ENH	PRM
Air pump	—	—	✓
All internally lubricated parts contained within the engine block and cylinder head(s)	✓	✓	✓
Belt tensioner and idler pulley(s)	—	✓	✓
Camshaft and Bearings	✓	✓	✓
Crankshaft and Bearings	✓	✓	✓
Coolant overflow tank	—	—	✓
Cylinder head	—	—	✓
Diesel fuel injection pump	✓	✓	✓
Diesel fuel injectors	—	—	✓
Diesel fuel lines	—	—	✓
Dipstick and tube	—	—	✓
EGR Valve	—	—	✓
Engine block and rotor housings when damaged as a result of the failure of a covered internally...	—	—	✓
Engine mounts	—	—	✓
Factory installed supercharger/turbocharger	—	—	✓
Fan	—	✓	✓
Fan Clutch	—	✓	✓
Fan shroud	—	✓	✓
Flex plate	—	—	✓
Flywheel	—	—	✓
Freeze plug	—	—	✓
Fuel cap	—	—	✓
Fuel pressure regulator	—	—	✓
Fuel pump	✓	✓	✓
Fuel tank	—	—	✓
Harmonic balancer	—	—	✓
Heater Core	—	✓	✓

ENGINE · CONT.	PWR	ENH	PRM
Exhaust Manifold	—	—	✓
Intake manifolds	✓	✓	✓
Oil cooler	—	—	✓
Oil pan	—	—	✓
Oil pressure switch	—	—	✓
Engine (complete assembly)	✓	✓	✓
Pistons and Piston Rings	✓	✓	✓
Rocker Arms and Push Rods	✓	✓	✓
Rotary Engine Rotors and Seals	✓	✓	✓
Rotary Engine Rotor Chamber	✓	✓	✓
Rotary Engine Eccentric Shaft and Bearings	✓	✓	✓
Radiator	—	✓	✓
Radiator cap	—	✓	✓
Ring gear	—	—	✓
Thermostat	—	✓	✓
Timing belt/chain	✓	✓	✓
Timing Gears	✓	✓	✓
Timing chain/belt cover	—	—	✓
Vacuum Pump	—	—	✓
Valve covers	—	—	✓
Valve Guides	✓	✓	✓
Valve Lifters	✓	✓	✓
Wrist Pin	✓	✓	✓
Water pump	—	✓	✓

FLUIDS & FILTERS	PWR	ENH	PRM
Coolant, fluids, lubricants, and filters when required in connection with a repair or replacement of a...	✓	✓	✓

HVAC	PWR	ENH	PRM
Coil and pulley	—	✓	✓
Compressor	—	✓	✓
Compressor clutch	—	✓	✓
Condenser	—	✓	✓
Dryer/accumulator	—	✓	✓
Evaporator	—	✓	✓
Expansion valve	—	✓	✓
Blower Motor	—	—	✓
Heater Control Valve	—	—	✓
Orifice	—	—	✓
Orifice Tube	—	—	✓

HYBRID & EV	PWR	ENH	PRM
Hybrid Battery Coverage	—	—	✓
Hybrid Specific Parts	—	—	✓

INTERIOR / EXT.	PWR	ENH	PRM
Lock cylinders	—	—	✓
Speedometer	—	—	✓
Speedometer cable	—	—	✓
Sub-frame mounts	—	—	✓
Tachometer	—	—	✓

SEALS & GASKETS	PWR	ENH	PRM
Seals and gaskets apply to the covered parts listed for vehicles with less than 125,000 miles. Minor loss...	✓	✓	✓

STEERING	PWR	ENH	PRM
Handle bars	—	—	✓
Idler arm	—	✓	✓
Pitman arm	—	✓	✓
Power steering pump	—	✓	✓
Rack and pinion assembly	—	✓	✓
Radius arm	—	✓	✓
Shaft coupling and bearings	—	—	✓
Steering gearbox	—	✓	✓
Steering column shaft	—	—	✓

DETAILED COVERAGE CHART · PART 2 OF 2

Every covered component, at a glance.

218 components across 14 vehicle systems.

✓ covered — not covered

STEERING · CONT.	PWR	ENH	PRM	SUSPENSION · CONT.	PWR	ENH	PRM	TRANSMISSION · CONT.	PWR	ENH	PRM
Steering sensors	—	—	✓	Torsion bars and bushings/mount	—	✓	✓	Automatically shifted manual transmission clutch	—	—	✓
Tie rod adjusting sleeve	—	✓	✓	Track bar and bushings	—	—	✓	Clutch master cylinder	—	—	✓
Tie rods and center link	—	✓	✓	Upper and lower ball joints	—	✓	✓	Clutch release bearing	—	—	✓
Triple clamp	—	—	✓	Upper and lower control arm shafts and bushings	—	✓	✓	Clutch slave cylinder	—	—	✓
SUSPENSION	PWR	ENH	PRM	Upper and lower control arm(s)	—	✓	✓	Dipstick and filler tube	—	—	✓
Suspension Compressor	—	✓	✓	Wheel bearings	—	✓	✓	Kick starter	—	—	✓
Suspension height control module	—	✓	✓	TRANSFER CASE	PWR	ENH	PRM	Oil pan only if damaged by internal parts	✓	✓	✓
Suspension Actuator	—	✓	✓	All internally lubricated parts contained within the transfer case	✓	✓	✓	Shift cable	—	—	✓
Suspension Solenoid	—	✓	✓	Electronic and vacuum engagement parts	—	—	✓	Shift linkage	—	—	✓
Suspension Height Sensor and Switch	—	✓	✓	Four wheel drive automatic/semi-automatic and manually operated hub assemblies	—	—	✓	Shifter assembly	—	—	✓
Coil springs and leaf springs	—	—	✓	Transfer case housing when damaged as a result of the failure of a covered internally lubricated part	✓	✓	✓	Torque Converter	✓	✓	✓
Double wishbone assembly	—	—	✓	TRANSMISSION	PWR	ENH	PRM	Transmission case when damaged as a result of the failure of a covered internally lubricated part	✓	✓	✓
Electronic level control compressor	—	—	✓	All internally lubricated parts contained within the transmission case	✓	✓	✓	Transmission cooler	—	—	✓
Sensor and limiter valve	—	—	✓	All internally lubricated parts contained within the manual transmission case	✓	✓	✓	Transmission cooler lines	—	—	✓
Spindle and spindle support	—	✓	✓					Transmission mount(s)	✓	✓	✓
Stabilizer bar and bushings	—	✓	✓					Vacuum modulator	—	—	✓
Stabilizer links	—	✓	✓					TECHNOLOGY	PWR	ENH	PRM
Steering knuckle	—	—	✓					Infotainment	✓	✓	✓
Struts	—	✓	✓								
Struts Bearing Plate	—	✓	✓								
Shock Absorbers	—	✓	✓								

IMPORTANT DISCLOSURES

Tint Mechanical Coverage is a vehicle service contract, not an insurance policy, sold by Tint Embedded Insurance Services, LLC ("Tint"), an authorized sales partner. Administrative and claims services are provided by Fair Tech Inc. (Fair Tech Services LLC in FL, VA, and OK). Contractual obligations are the responsibility of the obligor. Not all vehicles or customers qualify for coverage; eligibility depends on vehicle age, mileage, condition, and use. Coverage is not available through this program in California, Florida, or Massachusetts and may not be available in all other jurisdictions. Coverage terms, conditions, exclusions, and state-specific disclosures are governed exclusively by the Contract. If you apply, you're giving Turo permission to share your vehicle and listing information, including make, model, VIN, and location, with the parties named above to provide a quote and service your contract.